














LECTROCOUNT LCR 600 CPU 840404 WIRING SCHEMATIC

E3700/E3701



ESD PRECAUTION OPENING LECTROCOUNT REGISTERS
Before opening the LectroCount register and handling the CPU board, it is important to discharge any ESD that may have built up on your person. To discharge ESD from your person, touch a well-grounded point such as the LectroCount register housing, the meter, the truck piping, or the bumper. When the maintenance is complete and the LectroCount register door is closed, the CPU board is protected from ESD by the LectroCount register housing which is grounded to the chassis.



For positive ground installation, contact the Liquid Controls Service Department